



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	Stocked at Depot
1	8 in. Starter Section Assembly		22069B	Y
2	Brick Top Support - Left Side		32607	
3	Side Firebrick	Qty. 6 reg.	SRV7000-306	
4	Bottom Firebrick	Qty. 12 reg.	30419	
5	Grate		GR32	Y
6	Blower		FK23	
7	Heat Deflector/Hood		28171	
8	Top Grille Assembly		32832	
9	Filligree Front Face		32833	
10	Screen Rod		23305	Y
11	Lower Grille Assembly		32836	
12	Screen Handle		4021-150	
13	Damper Lever Knob		27971	
14	Junction Box Kit		22130	Y
15	Junction Box Plate		4048-234	
16	Air Kit Duct Assembly		28303	
17	Brick Top Support - Right Side		32606	
18	Damper Handle		32612	
	4 in. dia. Outside Air Duct - 42 in.		150012	
	Ashlip Firebrick	Qty. 4 reg.	28110	
	Blower Speed Control Kit		28331	
	Brick Bottom Support - Left Side		28317	
	Brick Bottom Support - Right Side		28318	
	Damper Kit		4016-006	Y
	Fan Retainer		28101	
	Gas Line Brick Support		28158	
	JK1 Fastener Pack		11920	
	Junction Box		21878	Y
	Nailing Flange	Qty. 4 reg.	31190	
	Outside Air Shield		33271	Y
	Screen Assembly	Qty. 2 reg.	33189	Y
	Screen Bracket		28125	
	Smoke Shield Kit		SRV4016-126	
	Strip Protector	Qty. 2 reg.	18320	
	Installation Instructions & Owner's Manual		32838	