



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	Stocked at Depot
1	Viewing Screen		4050-500	Y
2	View Screen Retainer		4050-501	Y
3	Glass Door (each side)		4050-502	Y
4	Refractory (each side)		4050-503	Y
5	Fuel Bed		4050-504	Y
6	Embers LED Assembly		4050-505	Y
7	Projector Assembly		4050-506	Y
8	Power Supply Assembly		4050-507	Y
9	3 Watt LED Bulb		4050-508	Y
10	Receiver		4050-108	Y
n/s	Installation Manual		4050-510	
n/s	Transmitter		4050-105	Y
n/s	Wall Switch		WSK-21	