



Part numbers on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Damper Blade Assembly		34487	
2	Starter Section Assembly		22072B	Y
3	Top Standoffs	Qty. 4 req.	4044-111	
4	Smoke Shield	Qty. 2 req.	16829F	
5	Refractory - Back	Qty. 2 req.	16672	
6	Refractory - Side	Qty. 4 req.	16948A	
7	Firescreen Assembly	Qty. 4 req.	12413	Y
	Firescreen Handle		4021-150	
8	Door Support	Qty. 2 req.	16697D	
9	Hearth Refractory		16673A	
10	Ashlip	Qty. 2 req.	16674B	
11	Grate		GR11	Y
12	Damper Control		16663	
13	Outside Air Kit		AK17	
14	Outside Air Plate Assembly		19081A	
15	Long Cable Tie	Qty. 2 req.	19954	
16	Outside Air Shield		33271	Y
	Fastener Pack		13580	
	Damper Weight		19785A	
	Door Pivot Clip	Qty. 2 req.	31527	Y
	Door Track (Lower)	Qty. 2 req.	15427	
	Door Track (Upper)	Qty. 2 req.	4012-001	
	Firescreen Rod	Qty. 4 req.	11755A	
	Gas Access Panel (for use with Air Kit)		31636	
	Grate Clip	Qty. 2 req.	28062	
	Nailing Flange	Qty. 8 req.	31190	
	Refractory Bracket	Qty. 4 req.	23959A	
	Refractory Retainer	Qty. 4 req.	16675B	
	Refractory Retainer	Qty. 4 req.	11847	
	Refractory Standoff	Qty. 6 req.	16678	
	Smoke Shelf	Qty. 2 req.	16676B	
	Smoke Shield Kit		SRV4012-036	
	Strip Protector	Qty. 4 req.	18320	
	Touch-Up Paint		71479	